
MacBook Core Duo Battery Replacement

MacBook Core Duo battery replacement.

Written By: iRobot



INTRODUCTION

If you've got a coin, you can replace the battery in your MacBook Core Duo.

TOOLS:

- Coin (1)

PARTS:


- MacBook Replacement Battery (1)

Step 1 — Battery



- Use a coin or spudger to rotate the battery-locking screw 90 degrees clockwise.

Step 2



- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-12-01 04:39:00 PM.